

# STIGA

## SBC 48 AE (2019)


272361008/S17



### Spare parts list Reservdelar Repuestos Ersatzteile Pièces détachées Reserve onderdelen Catalogo ricambi


- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permission in writing from ST. S.p.A.




# HH Brushcutter Battery

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	118804128/0	Front Handle Barrier			
2	1	118803270/0	Clamp			
3	1	118803326/0	Washer			
4	1	118803418/1	Front Handle			
5	1	118810710/0	Grommet			
6	2	6981102	Outfit, Screws			
7	1	118804121/0	Embrace hoop			
8	1	118803386/0	Housing			
9	1	118803293/0	Spring			
10	1	118803410/0	Button			
11	25	118804117/0	Conductor casing			
12	1	118803389/0	Cover			
13	6	118804114/0	Heat shrinkable tube			
14	2	118804116/0	Fork			
15	2	118804125/0	Rubber Washer			
16	2	118804124/0	Rubber Washer			
17	2	118804115/0	Sponge Gasket			
18	1	118804126/1	PCB Board			
19	1	118803304/0	Insert block			
20	1	118803344/0	Ring			
21	1	118803366/1	Electric Motor			
22	16	112728099/1	Screw			
23	1	123878121/0	Screw			
24	1	112727790/0	Screw			
25	1	112726389/0	Screw			
26	1	112581200/0	Grower			
27	1	118803407/0	Trigger			
28	1	118810712/0	Switch			
29	1	118804130/0	Support			
30	1	112154330/0	Nut			
31	1	6981101	Outfit, Screws			
32	1	118804129/0	Support			
33	1	118803347/0	Harness			
34	1	118804118/0	Tube			
35	1	118803274/0	Clamp			
36	1	2312090	Flat washer			
37	1	112581500/0	Grower			
38	1	112727796/0	Screw			
39	1	9988-3545-12	Screw			
40	1	118803425/0	Knob			
41	1	118810292/0	The Rod Set			
42	1	118810348/0	The Tube Components			
43	1	118810706/0	Upper Guard			
44	1	118810705/0	Guard			
45	4	118810322/0	Screw			
46	1	118810314/0	Protection			
47	2	118810711/0	Screw			
48	1	118810318/0	Line Cutter Blade			



# HH Brushcutter Battery

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
49	2	112728697/0	Screw			
50	2	112581500/0	Grower			
51	1	118810713/0	Gear Case Assy			
52	3	6981117	Washer			
53	1	118810326/0	Axle sleeve			
54	1	118810327/0	Blade fix seat			
55	1	118810312/0	Bowl			
56	1	1911-9196-01	Blade			
58	1	118810714/0	Tool Bar			
59	1	118810715/0	Blade Plate			
60	1	118810716/0	Dust Cover			
61	1	2452090	Nut			
70	1	1911-9224-01	Trimmer Head			



Please Note: These images are for illustrative purposes only.  
For more info see descriptions.

## Battery

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	270482518/S15	SBT 2548 AE	Stiga vers.		
1	1	270485018/S15	SBT 5048 AE	Stiga vers.		
2	1	270480028/S15	SCG 48 AE oplader	Stiga vers.		
2	1	270480128/S16	48V Fast Charger - EU plug	Stiga vers.		